

In-Reactor Measurement of Tritium Permeation through Stainless Steel Cladding

Presented by

Walter G. Luscher
D.J. Senor, C.D. Carlson, M.E. Cunningham,
K.K. Clayton, G.R. Longhurst

Presented at

32nd Tritium Focus Group Meeting
Germantown, MD
23-25 April 2013



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Presentation Outline

▶ Motivation

- Characterize in-reactor tritium permeation performance
 - Observe temperature and pressure dependence
 - Support predictive modeling and design efforts
 - Mitigate environmental release

▶ In-Reactor Permeation Test: *TMIST-2*

- Experimental description
 - ATR test position and irradiation environment
 - TMIST-2 capsule and measurement system
- In-reactor permeation measurements

▶ Summary and Conclusions



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Motivation

▶ Characterize in-reactor tritium permeation through Type 316 stainless steel



■ Fission Reactor

- Secondary Source Rods

■ Isotope-Producing Targets

- Tritium Producing Burnable Absorber Rods (TPBARS)

■ Fusion Reactor

- Containment Materials

▶ Support predictive modeling capabilities

■ Assess current estimates

■ Develop new correlations

▶ Mitigate tritium release to environment

■ Compliance with Regulatory Authority

■ Environmental Stewardship




Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Motivation

▶ TPBARs

- Support NNSA tritium readiness campaign
- Cladding exposed to low tritium partial pressures under commercial light water reactor conditions
- Must mitigate tritium permeation at low pressure



Not to Scale


Permeation Discussion

- ▶ Ex-reactor permeation measurements
 - $> 100 \text{ Pa} \rightarrow$ Diffusion-limited $\rightarrow P^{0.5}$
 - $< 100 \text{ Pa} \rightarrow$ Surface-limited $\rightarrow P^1$
- ▶ In-reactor permeation mechanism uncertain
 - Direct dissociative chemisorption
 - Molecules adsorb and readily dissociate upon contact
 - Disrupted ex-reactor at low pressure by:
 - ◆ Surface impurities / oxide films
 - Radiation-enhanced dissociation
 - Radiolysis of T_2 in gas phase
 - Physical or chemical changes in surface in-reactor

Permeation Discussion


► Pressure-dependent permeation

- Limiting mechanism changes
- Significantly impacts low pressure permeation rate



TMIST-2: In-Reactor Permeation Measurement



- ▶ Evaluate permeation performance for 316 Stainless Steel



- Temperature dependence (292° and 330°C)
- Pressure dependence (0.1, 5, 50 Pa)

Experimental Description (1/2)

- ▶ Experimental lead-out test assembly
 - Irradiated in Advance Test Reactor (ATR) at Idaho National Laboratory (INL)




**Test Assembly
located in
small B2
position**

Experimental Description (2/2)

- ▶ Test Irradiation
March 2009 -
April 2010
 - 5 ATR Reactor Cycles
 - Simulate WBN1 fast flux

Flux (n/cm ² -s)	ATR B-2	± %	WBN	± %
Thermal (< 0.5 eV)	1.67E14	13	2.95E13	10
Epithermal (0.5eV – 0.1 MeV)	1.51E14	16	1.19E14	10
Fast 2 (0.1 – 1MeV)	9.06E13	24	6.70E13	14
Fast 1 (>1 MeV)	7.28E13	8	6.00E13	10




- ▶ Flux wire analysis
 - 258 EFPD at 18MW
 - 1.63 dpa

Measurement System

► Ex-reactor measurement


- Pre-mixed source gas
- Sweep gas monitored by ion chamber
- Permeated tritium captured in bubbler column and measured via liquid scintillation counting



Results of Permeation Measurements

▶ 330°C Permeation Measurements


- Observed $P^{0.5}$ dependence
- Enhanced relative to predictions based on Le Claire correlation and ex-reactor tests with D_2



Results of Permeation Measurements

▶ 290°C Permeation Measurements

- Observed $P^{0.5}$ dependence
- Enhanced relative to predictions based on Le Claire correlation



Tritium Permeation Summary

- ▶ In-reactor measurements reveal $P^{0.5}$ pressure dependence
 - Indicates in-reactor permeation is diffusion-limited under test conditions
- ▶ In-reactor permeation enhanced relative to predictions based on Le Claire's ex-reactor permeability correlation
 - Permeation enhanced by a factor of $\sim 2 - 5$
- ▶ In-reactor measurements suggest permeation rates increase with temperature as expected
 - Data scatter precludes Arrhenius analysis of the temperature dependence
 - Consistent with weak temperature dependence noted in literature



^3He Analyses

- ▶ ^3He found in tritium-containing environments
 - Decay product of tritium
- ▶ Impact on tritium permeation uncertain
 - Tritium formation via neutron capture
 - Implanted tritium may contribute to permeation
- ▶ Evaluate contribution by supplying ^3He instead of tritium to cladding permeation experiment
 - 1013 Pa ^3He in 124 kPa ^4He at 330°C




Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

^3He Results

▶ Comparison

- Estimate transmutation /reaction rate based on local thermal flux
- Assume all implanted tritium permeates



- ## ▶ Less than 3% of the implanted tritium permeates
- Not a significant contribution to overall permeation

Summary and Conclusions

► In-reactor measurements

- Diffusion-limited permeation under test conditions
 - $P^{0.5}$ dependence at both temperatures
- Weak temperature dependence over studied range
- Enhanced permeation relative to predictions based on ex-reactor data
 - Significantly greater than predictions based on ex-reactor D_2 permeation data at > 100 Pa and P^1 dependence
 - Nominally a factor of ~ 2 -5 greater than extrapolation of Le Claire correlation
- ^3He contribution to permeation is small ($< 3\%$)





Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Selected References

R.A. Strehlow, H.C. Savage, Nucl. Tech. 22 (1974)127-137

A.D. Le Claire, Diffus. Defect Data 33 (1983) 1-66

A.D. Le Claire, J.Nucl. Mater. 122-123 (1984) 1558-1559

B.G. Polosuhin, E.P. Baskakov, et al., J.Nucl. Mater. 191-194 (1992) 219-220

W.G. Luscher, D.J. Senior, K.K. Clayton, G.R. Longhurst, J.Nucl.Mater. 437 (2013) 373-379



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965