

Overview of Tritium Activities at the Laboratory for Laser Energetics



W. T. Shmayda
University of Rochester
Laboratory for Laser Energetics

Tritium Focus Group Workshop
Germantown, Maryland
23–25 April 2013

Tritium operations are an integral part of the Inertial Confinement Fusion Program at LLE




- **LLE has operated a 1.5-g tritium facility since 2006 without a reportable incident**
- **Handling tritium gas over a 500°C temperature range and a 1000-atm pressure range poses unique challenges**
- **Volatile organic species and decay helium contaminate the DT fuel; a Pd permeator has been installed to remove these impurities**
- **LLE's tritium handling capabilities have expanded to address new programmatic needs:**
 - **DT layering studies**
 - **de-protination of the DT fuel**
 - **the study of DT fusion branching ratios**

The Laboratory for Laser Energetics operates two of the world's largest lasers for high-energy-density-physics research




- Operate the National Laser Users' Facility
- Conduct research and development in high-energy-density phenomena
- Provide undergraduate and graduate education in electro-optics, lasers, plasma physics, and fusion technology
- Conduct experiments in support of the National Inertial Confinement Fusion (ICF) Program


- Faculty-equivalent staff: 112
- Professional staff: 167
- Associated faculty: 21
- Contract professionals: 10
- Graduate and undergraduate students: 127



In 1996 LLE commissioned the Tritium Fill System (TFS) to permeation fill *gas targets*; since 2006 the TFS also delivers measured aliquots of gas to the DT high-pressure system (DTHPS) for cryo targets




Targets filled with DT gas are routinely fielded to study the physics of DT implosions



- Warm targets
 - diagnostic development
 - field 10 to 12 per campaign
 - 10 to 20 atm DT
 - <10 mCi per target
- Cryogenic targets
 - DT fusion reactions
 - field 4 to 5 targets per campaign
 - ~700 atm, 17 K DT ice
 - ~200 mCi per target
- Tritium Facilities
 - 1.5-g tritium inventory
 - released 0.6 Ci to the environment in 2012


All effluent streams are scrubbed to ensure LLE does not exceed its 9.6-Ci emission limit




The presence of air determines which technology is deployed to remove tritium from the effluent stream.

Effluent–air mixtures	Effluent without air
<ul style="list-style-type: none"> – catalytic oxidation – drier 	<ul style="list-style-type: none"> – drier to remove HTO – Ni to remove O₂ and crack organics – ZrFe to capture hydrogen gas

A Pd/Ag permeator has been installed to remove organic impurities and decay helium from the DT fuel






LLE has activated a new tritium laboratory to address expanding programmatic needs



- 3.2-Ci release limit; real-time monitoring of T emissions
- Lab is 0.05-in. H₂O negative relative to adjacent labs; seven air changes per hour
- Primary-loop effluents treated by dedicated tritium capture equipment
- Treated primary-loop effluents discharged into attendant independent glovebox cleanup systems


The glovebox purification systems are integrated, rack-mounted, engineered systems



- The mass transfer zone and capacity for oxygen uptake increase with temperature; higher operating temperatures are preferred

- Increasing the hydrogen concentration in the carrier increases the nickel reduction rate linearly at higher flow rates


A DT cryolayering facility will study advanced cryogenic target designs to be fielded on the National Ignition Facility (NIF)



- Targets being examined include:
 - polar-drive targets
 - capsules in transparent hohlraums
 - cone-in-shell targets


NIF baseline: All cryogenic targets are fueled using a fill tube.

A test stand to produce and characterize the advanced cryogenic targets has been constructed and tested with D₂




- Optical and x-ray wavelengths are used to characterize targets

The layering sphere is thermally isolated, controlled separately, and provides primary containment for the DT






The target assembly comprises four gas compartments: D_2 and T_2 reservoirs, shell, and cover assembly



- The cover assembly provides containment for target transfer from T₂ dispensing loop to layering facility

Metal seals are used throughout. The leak rate between adjacent compartments and the exterior is $<10^{-8}$ sccm He.

The tritium dispensing loop uses a Pd bed for all dispensing and recovery operations; T₂ is stored on U




An isotope separation system (ISS) will provide LLE with a flexible tritium fuel supply



- **Ensure the D/T ratio of the fuel supply meets LLE's baseline ICF program requirements**
- **Eliminate protium from the existing fuel supply**
- **Recover tritium from existing, unusable spent DT fuel**
- **Eliminate the need to ship tritium to/from external cleanup facilities**
- **Provide the ability to examine fusion reactions at variable D/T ratios**


The ISS can process 5 L/day and supports several novel features



Acoustically drive cryogenic cooler to cool Pd bed to 77 K


20 cc “wall-less” high-activity tritium monitor

500-psig ASME certified tritium monitor



ISS based on Savannah River National Lab (SRNL) μ TCAP design

The gas handling system used to support the ISS comprises flow through uranium and palladium beds



**Flow through U-bed
cross section**


- Both beds have a maximum working inventory of 5 liters of hydrogen gas
- Beds have a secondary containment to capture permeant tritium and for thermal isolation
- Compact design to permit gas circulation through the “getter” medium
- The uranium bed will be used for tritium storage
- The palladium bed will be used to “pump” tritium inside the gas handling loop

The gas chromatograph permits baseline separation of all six hydrogen isologues




Zr-Fe-based effluent collector

1/8-in.-diam nickel column contains Fe-doped Al_2O_3



Aluminum mandrel provides uniform temperature for the column



Tritium operations are an integral part of the Inertial Confinement Fusion Program at LLE



- **LLE has operated a 1.5-g tritium facility since 2006 without a reportable incident**
- **Handling tritium gas over a 500°C temperature range and a 1000-atm pressure range poses unique challenges**
- **Volatile organic species and decay helium contaminate the DT fuel; a Pd permeator has been installed to remove these impurities**
- **LLE's tritium handling capabilities have expanded to address new programmatic needs:**
 - **DT layering studies**
 - **de-protination of the DT fuel**
 - **the study of DT fusion branching ratios**